使用说明书 User Manual

使用产品前请仔细阅读本使用说明书,并保留备用。 Before using the product,please read the User Manual carefully and keep it for future reference.

ΤΟΤΟ



产品型号:见包装箱上的标签 产品名称:见包装箱上的标签 生产日期:见包装箱上的标签

检印	合格	
	东陶机器(广州 广州市番禺区南	〕有限公司 时镇兴南大道715号

东陶(中国)有限公司 全国售后服务电话: 800-820-9787(固定电话) 400-820-9787(手机用户)



扫描—维码, 服务预约,方便快捷

销售商:东陶(中国)有限公司 地 址:北京市朝阳区光华路1号北京嘉里中心北楼1915室

网 址: www.toto.com.cn

0G267G(E) 2023.07

日录
目录1
明细单
使用条件与使用上的注意3-4
使用上的注意与保养4
产品示意图5
拆卸与检查6
保证书7

明细单	
k嘴主体	1套
时压软管	2条
非水金具	1套
圆体	2套
巴手部	2套
是拉杆	1条
迤工说明书	1本
吏用说明书	1本
使用此明细单的产品包括: TLS01201* 铜合金台式双柄双控洗面器水嘴 TLS02201* 铜合金台式双柄双控洗面器水嘴	
	K嘴主体····································

TOTO Asia Oceania Pte. Ltd.

Telephone : 65-6744-6955

FAX: 65-6841-0819

Address : 10 Eunos Road 8 #12-07 Singapore Post Centre

Singapore 408600

Website : asia.toto.com

TOTO KOREA LTD.

전화번호 : **(02)-3141-8236**

FAX 번호: (02)-3141-8240

주소 : 서울시마포구 상수동 351-16 번지 로이코빌딩 3층

홈페이지 : https://kr.toto.com/

Guarantee

User	
Sales shop or installation shop	
Date of buying	
	The body and valve spool warranty is valid for 5 years from the date of purchase, and the remaining parts are warranted for 1 year.
be deemed as invalid. Theref buying. * The items covered in this pro repair items as agreed in the	any failure occurs to the product (water leakage, seepa-
 During the warranty period, according to relevant instruct repair to any faulty product. When any free repair is requarter sale service to request Within the warranty period, to Any failure and damage du modification conducted privation (2) Any failure and damage re- construction. Any failure and damage re- construction. Any failure and damage at installation, etc. Any failure and damage du specified scope of use (for ex- purpose). Any failure and damage du such adverse results as di daily maintenance and care. Any failure and damage du natural disasters, public nuis abnormal voltage, use of any specified ones, etc. The occasions not specifie The occasion in which the is not filled in. No buying invoice can be p 	hired due to damage within the warranty period, please call repairs. he repair in the following occasions is paid repair. le to any improper use or any improper repair and tely. sulting from any carelessness or fault in installation tributed to such reasons as removal for relocation after le to using this product in occasions beyond the xample, home commodity is used for any business and grains or dirt, etc. rtiness, plating part rusting, etc. attributed to improper ue to fire, earthquake, flood, lightning strike and other ances, gas damage (liquefied gas), salt damage and v power supply (voltage, frequency) other than the ed in this warranty. user name, sales shop, installation shop or buying date poresented.

使用条件与使用上的注意

使用条件

1.供冷水*热水压力:

最低压力………0.05MPa (流动压)

最高压力……1.0MPa (静压)

推荐使用压力……0.1~0.5MPa (流动压)

- 检测压力……1.6MPa (静压)
- 2.供水温度在4℃~90℃,建议使用热水温度60℃,供热水请勿使用蒸汽。
- 3.使用环境温度0℃以上。如果不高于0℃,水嘴会出现变形、冻裂现象。
- 4.长时间不使用时,可能导致水嘴内部及外部锈蚀不能使用等现象。
- 5.如果您需要废弃本产品,请勿将其作为一般生活垃圾处理,请依照法规经 由独立的回收体系进行合适的处理、恢复和回收。

6.本说明书中的产品具有清洗功能。

使用上的注意

▲警告 表示如果无视此标志而误操作时,有可能造成人员重伤或死亡。

△ 注意 表示如果无视此标志而误操作时,有可能造成人身伤害或财产损失。

⚠警告

- 1.幼儿禁止使用或幼儿需要由成年人监护使用、老人和残障人士等特殊 群体应在有行动能力人员陪同下使用。
- 2.水嘴的供热水一侧处于高温状态,请注意勿使皮肤直接接触五金配件 表面,否则可能会烫伤。

3.请勿配反冷*热水配管,否则可能会烫伤。

4.供热水请勿使用蒸汽,否则可能会烫伤。




1.由于陶瓷阀芯是较精密的部件,请勿擅自分解,否则可能会造成漏水 等不良。

使用上的注意与保养


Dismantle and Inspection

_	
	⚠注意
	2.请勿撞击本产品,否则可能会造成故障、漏水。 3.必须使用中性洗涤剂清洗,中性以外的洗涤剂会破坏镀层或使表 面变色。
	4.不得使用酸性洗涤剂和去污粉、抛光粉等含粗颗粒的洗涤剂和尼龙刷, 否则可能会破坏镀层等。
	5.可使用软布擦拭或用机油或车用蜡浸布擦拭,但请勿接触树脂部 件,否则可能失去光泽和产生锈蚀。 5.建议不要长时间不使用,否则可能会导致水嘴内部以及外部锈蚀不能
	,建成不安长时间不使用,百刻可能要导致水偏内部以及外部诱强不能 使用等现象。 7.如果吐水压力大,请调节止水阀达到需要的流量,避免水势过大,溅
8	出洗脸盆。 3.随着产品式样的不断更新,实物存在与图示不符的情况,但基本安装、 使用原理相同。
9	9.在可能结冰的场所使用时,要切实做好防冻措施。 由于结冰,零件破损,有可能导致漏水,造成财产损失。因结冰而造 成的破损即使在保修期内也是有偿修理。请不要让产品的温度低于0℃。
	防冻措施
	在可能结冰的场所使用时,要切实做好防冻措施。 1. 产品结冰的话零件损坏,成为漏水的原因。 2. 因结冰造成的零件损坏即使在保修期内也是有偿修理。 3. 施工完了后或长时间不使用时,要有预防突然降温的准备,要对 产品进行结冰预防。
	4. 因为有结冰的危险,请不要让产品周围的温度在0℃以下。
	保养
	为长期保持产品的美观,请用户按以下方法维护保养。





4

Product schematic diagram



产品示意图





Attentions in use and maintenance

▲ Attentions	
2. Do not impact the product. Otherwise, failure, water leakage may occur.	
3. It is imperative to use a neutral detergent in cleaning. Other detergents	
than a neutral one may damage the plating coat or make the surface discolor.	
4. Do not use any such detergent as acidic detergent and abstergent, polishingpowde	r,
etc. containing thick particles and nylon brush. Otherwise, the plating coat may be	
damaged, etc.	
5. It is allowed to use a piece of soft cloth to wipe or use from time to time a piece of	
cloth immersed in machine oil or vehicle wax to wipe. However, do not contact with	
resin components. Otherwise, they may lose the gloss and become rusty.	
6. It is suggested not to leave it unused for a long time. Otherwise, this may lead to	
internal and external rust to faucets to such a degree that it cannot be used any	
more, etc.	
7. If the water outlet pressure is too high, please adjust the water valve to the water	
flow you need to avoid the water sprinkled out the basin.	
8. With the product design being updated constantly, the physical object may not	
coincide with the figure. However, the basic principle for installation, use is the sam	
9 .When using in places where frost damage may occur, anti-freezing measures must	
be taken.	1
The parts will be damaged due to frost damage, which may cause water leakage and	
property loss. Damages caused by frost damage are repaired for a fee even during	
warranty period. Please ensure that the ambient temperature of the product is alwa above 0℃.	ays
	=
(Anti-freezing measures)
When using in places where frost damagemay occur, anti-freezing measures must be tal	ken.
1. The parts will be damaged due to frost damage, which may cause water leakage.	
Damaged parts caused by frost damage are repaired for a fee even during the warrant period.	ty
3. After the construction is completed or when it is not used for a long time, prepare to	
prevent sudden drop of temperature and prevent the product from frost damage.	

prevent sudden drop of temperature and prevent the product from frost damage. 4. Because of the risk of frost damage, please ensure that the ambient temperature of the product is always above 0°C.

Maintenance

To maintain a beautiful appearance of the product, the user is requested to conduct maintenance and care in the following method.

- 1. Wipe with a piece of soft cloth frequently and use a piece of soft cloth dipped in water to wipe from time to time.
- 2. When dirt exists obviously, please use water to wash sufficiently after wiping with a neutral detergent.

Use condition and attentions in construction

 Cold water supply*hot water supply pressure
Minimum pressure 0.05MPa (flow pressure)
Maximum pressure 1.0MPa (static pressure)
Recommended Operating pressure 0.1~0.5MPa (flow pressure)
Test pressure

2. The temperature for water supply is 4~90 ℃. It is recommended hot water temperature of 60 ℃, Do not use steam to supply hot water.

- 3. The ambient temperature for use is above 0° C. If the ambient temperature is lower than 0° C, the faucets will deform and crack from freezing.
- 4.Being out of use for a long time may result in internal and external rust to the faucets and being unable to be used.
- 5.If you want to scrap this product, do not treat it as you do for general household garbage. Please follow relevant statutes to have it treated, recovered and collected appropriately by an independent recovery system.
- 6. The product in these instructions has a cleaning function.

Attentions in using

Warning: it means that ignoring this mark and misoperation may cause serious - personal injury and death.

Attention: it means that ignoring this mark and misoperation may cause personal injury or property loss.

AWarning

- 1. Children are not allowed to use or can use only under the custody of adult. Such special groups as the aged and disabled should be accompanied by those with behavioral competence when using it.
- 2. The hot water supply side of the faucets is in a condition of high temperature. Do not allow skin to contact with the hardware surface directly. Otherwise, scalding may occur.
- 3. Do not reverse the cold*hot water pipes. Otherwise scalding may occur.
- 4. Do not use steam to supply hot water. Otherwise, scalding may occur.

Attentions 1

1. As the ceramic cartridge is a precise component, do not dismantle it without authorization. Otherwise, such poor conditions as water leakage, etc. may be caused.

保证书

用户	
销售安装店	
购买日	
保修期	自购买日起本体及阀芯保修有效期5年, 其余部件保修期为1年。
进行确认。	全,该保证书将视为无效。因此请用户购买时对记入内容 的保修项目仅限于保证书中所约束的免费维修项目进行维
修。	产品发生故障 (漏水、渗漏),请拨打全国售后服务电话
	维修规定
的情况下,本公	户正确按说明书、不干贴等指示,使用本公司产品 司将对有故障产品进行免费维修。 损坏需要得到免费维修时, 请拨打全国售后服务电话
 ① 使用不当或私 ② 安装施工时的 	面所列场合的维修为有偿维修。 自进行的不当修理及改造所造成的故障及损伤。 不注意或过失造成的故障及损伤。 等原因造成的故障及损伤。
④超出使用范围	以外的场合下使用本产品所造成的故障及损伤(如家庭 务上商品使用)。
⑦ 由于火灾、地 盐害及异常电 障及损伤。	护保养不当造成的肮脏、电镀部分生锈等不良。 震、水灾、雷击及其他天灾、公害、气害(液化气)、 压、使用指定外的电源(电压、频率)等原因造成的故
 ⑧本保证书没有 ⑨本保证书中用 ⑩不能出示购买 ⑪由结冰引起的 	户姓名、销售店、安装店、购买日期未填写的场合。 发票的场合。
4.本保证书只在中	国境内有效。 (香港、澳门、台湾地区除外) 补,请顾客妥善保管。

Contents

Contents		
Contents ······1		
Detailed list 2		
Use condition and attentions in		
construction 3-4		
Attentions in use and maintenance4		
Product schematic diagram5		
Dismantle and inspection6		
Guarantee7		

Detailed list

Detailed list
Main body of faucets······1 set
Pressure-resistant hose······2 pieces
Water drainage hardware1 set
Valve body ······2 sets
Handle part ······2 sets
Lifting bar 1 piece
Instructions for construction1 copy
Instructions for operation1 copy
The products using this detailed list include: TLS01201* "LB" Wide Spread Faucet TLS02201* "LN" Wide Spread Faucet