TOTO

使用说明书 User Manual

使用产品前请仔细阅读本使用说明书,并保留备用。 Before using the product, please read the User Manual carefully and keep it for future reference.

TOTO

0G495Y(B) 2020.09

目 录

目 录	1
明细单	2
使用条件与使用上的注意	3
使用上的注意与保养	4
产品示意图	5
拆卸与检查	6
产品保修卡	7
合格证	8

明细单

明细单

水嘴主体部1套
耐压软管 2根
排水金具 1套
阀芯本体部 ······· 2套
手柄部2套
吐水口拆卸治具1个
施工说明书1本
使用说明书1本
使用此明细单的产品包括: TLG07201* 铜合金台式双柄双控洗面器水嘴(含排水配件) TLG08201* 铜合金台式双柄双控洗面器水嘴(含排水配件) TLG09201* 铜合金台式双柄双控洗面器水嘴(含排水配件) TLG10201* 铜合金台式双柄双控洗面器水嘴(含排水配件) TLG11201* 铜合金台式双柄双控洗面器水嘴(含排水配件)

使用条件与使用上的注意

使 用 条 件

1. 供冷水*热水压强:

最低压强 ·········0.05 MPa (流动压)

最高压强 ·······1.0MPa (静压)

推荐使用压强……0.1~0.5MPa(流动压)

检测压强 ·······1.6MPa (静压)

- 2. 供水温度在4℃~90℃,建议使用热水温度60℃,供热水请勿使用蒸汽。
- 3. 使用环境温度0℃以上。如果不高于0℃,水嘴会出现变形、冻裂现象。
- 4. 长时间不使用时,可导致水嘴内部及外部锈蚀不能使用等现象。
- 5. 如果您需要废弃本产品,请勿将其作为一般生活垃圾处理,请依照法规经由独立的回收体系进行合适的处理、恢复和回收。
- 6. 本说明书中的产品具有清洗功能。

使 用 上 的 注 意

★警告表示如果无视此标志而误操作时,有可能造成人员重伤或死亡。

⚠ 注意 表示如果无视此标志而误操作时,有可能造成人身伤害或财产损失。

▲警告

- 1. 幼儿禁止使用或幼儿需要由成年人监护使用、老人和残障人士等特殊 群体应在有行动能力人员陪同下使用。
- 2. 水嘴的供热水一侧处于高温状态,请注意勿使皮肤直接接触五金配件表面,否则可能会烫伤。
- 3. 请勿配反冷*热水配管,否则可能会烫伤。
- 4. 供热水请勿使用蒸汽, 否则可能会烫伤。

▲注意

1. 由于陶瓷阀芯是较精密的部件,请勿擅自分解,否则可能会造成漏水等不良。

使用上的注意与保养

▲注意


- 2. 请勿撞击本产品,否则可能会造成故障、漏水。
- 3. 必须使用中性洗涤剂清洗,中性以外的洗涤剂会破坏镀层或使表面 变色。
- 4. 不得使用酸性洗涤剂和去污粉、抛光粉等含粗颗粒的洗涤剂和尼龙刷, 否则可能会破坏镀层等。
- 5. 可使用软布擦拭,间或用机油或车用蜡浸布擦拭,但请勿接触树脂部件,否则可能失去光泽和产生锈蚀。
- 6. 建议不要长时间不使用,否则可能会导致水嘴内部以及外部锈蚀不能使用等现象。
- 7. 如果吐水压力大,请调节止水阀达到需要的流量,避免水势过大, 溅出洗脸盆。
- 8. 随着产品式样的不断更新,实物存在与图示不符的情况,但基本安装、使用原理相同。

保 养

为长期保持产品的美观, 请用户按以下方法维护保养。

- 1. 经常用软布擦拭,间或用软布蘸水擦拭。
- 2. 当有污垢且较明显时,请用中性洗涤剂擦拭后充分进行水洗。

产品示意图



拆卸与检查

现 象	检 查 项 目
水流量小	1, 8, 11
手柄晃动	7, 8, 9, 10
漏水	1, 2, 3, 4, 5, 8, 11, 12
本体晃动	6
安装后万一出现故障,请按以T 领拆卸。	长条形吐水口拆卸场合 吐水口
(此图内未拆分的零部件,需要的情况下,请联络售后服务人员 行拆卸)	
例: TLG07201*	吐水口が
吐水口 (1. 垫片有无划	※拆卸时,请确认滤网是否遗漏本体内。
1. 查片紧? 方、一个一个一个一个一个一个一个一个一个一个一个一个一个一个一个一个一个一个一个	六角扳手 公制2mm (非附送) 内六角螺钉 (非附紧) 内六角螺钉 (7. 是否在 后之 一个一个一个一个一个一个一个一个一个一个一个一个一个一个一个一个一个一个一个
間整花键 □ TLG08201* □ 手柄部有调整 □ 角度花键 □ 耐压软管 (5. 是否充分 ○ 型圈有无力	
※不同示例产品的拆卸与原理	基本相同

产品保修卡

- *若上栏内容未记全,该保证书将视为无效。因此请用户购买时对记入内容讲行确认。
- *本产品保修卡中的保修项目仅限于保证书中所约束的免费维修项目进行维修。
- *在保修期间,若产品发生故障(漏水、渗漏),请拨打全国售后服务电话报修。

免费维修规定

- 1. 保修期间,在用户正确按安装说明书、不干贴等指示,使用本公司产品的情况下,本公司将对有故障产品进行免费维修。
- 2. 在保修期内发生损坏需要得到免费维修时,请拨打全国售后服务电话报修。
- 3. 在保修期内,下面所列场合的维修为有偿维修。
 - ① 使用不当或私自进行的不当修理及改造所造成的故障及损伤。
 - ② 安装施工时的不注意或过失造成的故障及损伤。
 - ③ 安装后又拆移等原因造成的故障及损伤。
 - ④ 超出使用范围以外的场合下使用本产品所造成的故障及损伤(如家庭用商品作为业务上商品使用)。
 - ⑤沙粒或污物等造成的损伤。
 - ⑥ 由于日常的维护保养不当造成的肮脏、电镀部分生锈等不良。
 - ⑦ 由于火灾、地震、水灾、雷击及其他天灾、公害、气害(液化气)、 盐害及异常电压、使用指定外的电源(电压、频率)等原因造成的故 障及损伤。
 - ⑧ 本保证书没有指定的场合。
 - ⑨ 本保证书中用户姓名、销售店、安装店、购买日期未填写的场合。
 - ⑩ 不能出示购买发票的场合。
- 4. 本保证书仅适用于中国国内。
- 5. 本保证书丢失不补,请顾客妥善保管。

合格证

本品经检查判定合格

执行标准: GB 18145-2014、GB 25501-2019

产品型号: 见包装箱上的标签

产品名称: 见包装箱上的标签

生产日期:见包装箱上的标签

组装工厂: 东陶(大连)有限公司

电 话: (0411) 87624383

厂 址: 大连经济技术开发区东北二街17号

东陶(中国)有限公司

全国售后服务电话: 800-820-9787(固定电话)

400-820-9787(手机用户)



扫描二维码, 服务预约,方便快捷

销售商: 东陶(中国)有限公司

地 址:北京市朝阳区光华路1号 北京嘉里中心北楼1915室

网 址: www.toto.com.cn

Table of Contents

Table of Contents

Table of Contents1
Specification2
Conditions and Attentions for Use 3
Attention and Maintenance for Use 4
Product Structure Diagram 5
Disassembly and Inspection6
Product Warranty Card ······7

Specification

Specification		
Main Body of the Spout1 set		
Water supply hose2 pieces		
Drain Assembly1 set		
Valve Spool Body2 sets		
Handle2 sets		
Fixture for Disassembly for Spout1 piece		
Installation Manual1 booklet		
User Manual1 booklet		
Products using this specification include TLG07201* "GE "Wide spread lavatory faucet TLG08201* "GC"Wide spread lavatory faucet TLG09201* "GM" Wide spread lavatory faucet TLG10201* "GB" Wide spread lavatory faucet TLG11201* "GF" Wide spread lavatory faucet		

Conditions and Attentions for Use

Use Conditions

- 1.Pressure for cold water * hot water supplying
- Minimum pressure.......0.05 MPa (flow pressure)
- Maximum pressure........ 1.0 MPa (static pressure)
- Recommended pressure........0.1 ~ 0.5 MPa (flow pressure) Detection pressure.......1.6 MPa (static pressure)
- 2.The water supply temperature is between 4° C and 90° C. It is recommended to use hot water temperature of 60° C. Do not use steam when supplying
- 3.Ambient temperature of the use above 0° C. If it is lower than 0° C, the spout will have some issues such as deformations, cracking, etc.
- 4. When it is not used for a long time, it may cause the inside and outside of the spout to rust and corrode, leading to malfunction.
- 5. If you need to dispose of this product, do not dispose of it as general household waste. Please follow the regulations to properly dispose, recover and recycle it through an independent recycling system.
- 6. The products stated in the Manual have a cleaning function.

Attention for use

- Warning: Indicates that if you overlook this sign, causing misoperation, it may $^{\perp}$ result in serious injury or death.
- Attention: Indicates that if you overlook this sign, causing misoperation, it may cause personal injury or property damage.

⚠Warning

- 1. Children are prohibited from using it or need to be supervised by adults when using it, and special groups such as the elderly and the disabled should be accompanied by people with physical capacity when using it.
- 2. As one side of the spout to supply hot water is in a high-temperature state, do not let the skin be directly in contact with the surface of the hardware fitting; otherwise it may cause burn injuries.
- 3.Do not assemble cold * hot water tubing incorrectly; otherwise it may cause burn
- 4.Do not use steam when supplying hot water; otherwise it may cause burn injuries.

⚠ Attention

1. Since the ceramic valve spool is a relatively precise component, do not disassemble it without authorization; otherwise it may cause water leakage and other defects.

Attention and Maintenance for Use


Attentions

- 2.Do not hit this product; otherwise it may cause malfunction or water leakage.
- 3.It must be cleaned with a neutral detergent as other detergents will damage the coating or discolor the surface.
- 4.Do not use acidic detergents or detergents containing coarse particles, such as cleaning powder and polishing powder, and nylon brushes, as they may damage the coating, etc.
- 5. It can be wiped with a soft cloth, or wiped with machine oil or a cloth soaked with paraffin for cars occasionally, but do not let them be in touch with the resin parts; otherwise they may lose luster or generate rust.
- 6. It is recommended not to use it for a long time; otherwise it may cause the rust and corrosion inside and outside of the spout, resulting in malfunction.
- 7. If the water outlet pressure is too high, please adjust the water stop valve to reach the required flow to avoid excessive water splashing out of the lavatory.
- 8.As the product model is constantly updated, the actual product may not look the same as it is shown in the diagram, but the basic installation and operation principles are the same.

Maintenance

- In order to maintain the decent appearance of the product for a long time, please maintain it according to the following methods.
- 1. Wipe with a soft cloth often, or wipe with a soft cloth with water occasionally.
- 2. When there is dirt and it is obvious, please wash it with water thoroughly after wiping it with neutral detergent.

Product Structure Diagram



Disassembly and Inspection

Issues	Inspection item
Small water flow	1、8、11
Handle shaking	7、8、9、10
Water leakage	1、2、3、4、5、8、11、12
Shaking of the body	6
following instructions. (For the parts not	ation, please disassemble it according to the Disassembly occasion for water spout
disassembled in this figure, if they need to be disassembled, please contact the after–sale service personnel for disassembly)	es Screen filter Water spout
Example: TLG07201* Water spout	1. Is there any dirt in the filter? 2.0—ring are there any scratches or dirt?
(1. Is the gasket scratched or	Fixture for disassembly for spout *When disassembling, please confirm
tightened? Is there any dirt in the filter?)	whether the filter screen is left in the body. Hex wrench
for disassembly	2mm (not included)
for spoul	Hexagon socket head
O-ring (2. Are there any scratches	cover screws (7.Is it fully tightened?) Collar
or dirt?)	Washer Cartridge (3. Sufficiently tightened?
Connecting pipe (3.Is it fully tightened?)	Valve body Any scratch, dirt on O-ring or rubber gasket?)
Gasket	oring Rubber gasket Gasket
any dirt	astening nut Fastening nut (9. Sufficiently
	ightened?) Gasket
O-ring	(11.Is there any dirt or scratch?) Screw (10. Sufficiently
Adjustment Pressure resistant hose	`tightened?)
TLG08201* (5. Sufficiently	Fastening nut (12. Sufficiently
for angle tightened? Any scratch, dirt on the	tightened?)
handle part O-ring?)	

Product Warranty Card

User	
Sales and installation stores	
Date of purchase	
Warranty period	The warranty is effective for a period of one (1)year from the date of purchase.

- * If the contents on the above column are not recorded completely, the warranty card will be considered invalid. Therefore, please confirm the recorded contents at the time of purchasing.
- * The warranty items in this product warranty card are limited to the free repair items covered by the warranty card for maintenance.
- * During the warranty period, if the product breaks down (such as water leakage, oozing), please call after sale service to request repairs

Free repair provisions

- During the warranty period, under the condition that the users use the company's
 products in accordance with the operation instructions and the instructions on the
 adhesive labels, etc., the company will repair the malfunctioning products for free.
- 2. If damage occurs in the warranty period is required to be repaired for free, please call after sale service to request repairs.
- 3. During the warranty period, the repairs with the following situations are charged.
 - 1) Failure and damage caused by improper use, or improper repair or modification without authorization.
 - 2 Failure or damage caused by inattention or negligence during the installation.
 - 3 Failure and damage caused by disassembly after installation.
 - 4 Failures and damages caused by using this product in the sites outside the scope of use (such as household goods used as a commercial product).
 - ⑤ Damage caused by sand or dirt.
 - 6 Failure and damage caused by disassembly after installation.
 - Tailures and damages caused by fire, earthquake, flood, lightning and other natural disasters, public hazard, gas damage (liquefied gas), salt damage and abnormal voltage, use of the non–specified power source (voltage, frequency) and other reasons.
 - The installation locations not specified in this warranty card.
 - For the occasions that the user name, sale store, installation store, and the date
 of purchase are not filled in this warranty card.
 - 10 For the occasions that the user is unable to present the purchase invoice.
- 4. This warranty applies to countries except China.
- 5. This warranty card may not be replaced when it is lost. Please keep it properly.

TOTO Asia Oceania Pte. Ltd.

Telephone:65-6744-6955

FAX: 65-6841-0819

Address: 10 Eunos Road 8 #12-07 Singapore Post Centre

Singapore 408600

Website:asia.toto.com

TOTO KOREA LTD.

전화번호 : (02)-3141-8236

FAX 번호 : (02)-3141-8240

주소: 서울시 마포구 상수동 351-16번지 로이코빌딩 3층

홈페이지: http://www.totokr.co.kr